


PLASTIC LOGIC





Adafruit Feather EvalKit instruction


1. **Arduino IDE** installed or download the latest version from [here](#).
2. please add the new board to the Arduino IDE: Please go to **FILE > PREFERENCES** and add https://adafruit.github.io/arduino-board-index/package_adafruit_index.json as an Additional Board Manager URL



- After restart of the IDE please open the **Boards Manager** from the **Tools -> Board menu** and install **Adafruit nRF52** by **Adafruit**. It will take a few minutes to finish installing the cross-compiling toolchain and associated tools. Then please select the board **Adafruit Feather nRF52840 Express**, and after connecting the board via USB, please select the newly appeared serial COM port for your device under **Tools --> Port** and you should be ready to go for programs.




- Open the Tools -> Manager Libraries, search Adafruit GFX and download this library
- Then download the PL_smallEPD Arduino Library: [plasticlogic/PL_smallEPD: This is a library for UC8156-based E-Paper displays \(EPD\) from Plastic Logic for Adafruits GFX library. \(github.com\)](https://github.com/plasticlogic/PL_smallEPD)
- Unzip the library under the path: **C:\Users\xxxxx\Documents\Arduino\libraries**
- After restart the Arduino IDE you can find the example under **File > Example > PL_smallEPD > Examples**



Example


04_Slideshow -> 2.1" Legio (6 colors)



07_S021_Tricolor_Red -> 2.1" tricolor red




08_S021_Lectum4GL -> 2.1" Lectum (4 grey levels)




Support program

You can find the small program [image converter](#), which with Microsoft Visual Studio supports these three displays . For execution Just download the [PL_smallEPD_image_converter_exe.zip](#)



Support program

Click choose and select your image with format “.jpg”, “.png”, “.bmp”, “.pgm”



A “.h” head file will be automatically created.
Copy it to your arduino program folder and use it

RGB value

Lectum (4 GL) :

black(grey level 0)	<0x00,0x00,0x00>;
grey level 4	<0x44,0x44,0x44>;
grey level 11	<0xAA,0xAA,0xAA>;
white(grey level 15)	<0xFF,0xFF,0xFF>

Legio (6 colors):

black <0,0,0>;
white <0xFF,0xFF,0xFF>;
red <0xFF,0x00,0x00>;
green <0x00,0xFF,0x00>;
blue <0xFF,0xFF,0xFF>;
yellow <0xFF,0xFF,0x00>;

Tolerance:

black: $R \leq 0xCD \ \&\& \ G \leq 0xCD \ \&\& \ B \leq 0xCD$;
white: $R \geq 0xCE \ \&\& \ G \geq 0xCE \ \&\& \ B \geq 0xCE$;
red: $R \geq 0xAF \ \&\& \ G \leq 0x50 \ \&\& \ B \leq 0x50$;
green: $R \leq 0x50 \ \&\& \ G \geq 0xAF \ \&\& \ B \leq 0x50$;
blue: $R \leq 0x50 \ \&\& \ G \leq 0x50 \ \&\& \ B \geq 0xAF$;
yellow: $R \geq 0xAF \ \&\& \ G \geq 0xAF \ \&\& \ B \leq 0x50$;